



6-in-1 Multi-Use Opener

INSTRUCTION MANUAL

Model No. EL12474

Please read carefully before use and keep for future reference


Using 6-in-1 Can Opener

1. Flip out handle until it 'clicks' into place.
2. Make sure the Cutter is in the start position by turning the handle counter-clockwise (1-2 rotations).
3. Place the Can Opener on the can. Please note: The can alignment arrows on the Can Opener should line up with the rim of the can.
4. Rotate the handle clockwise until the can is open.
5. When the can is opened the lid will be held by the Can Opener. To release the lid from the opener, rotate the handle counter-clockwise.
6. After use, flip the handle back into the resting position, inserting the knob into the hole.

CAUTION! Keep out of children's reach.

Cleaning and Care

- Wipe the unit with a damp cloth or a sponge, using a mild non-abrasive cleaner, followed with a clean and dry cloth to dry it completely.
- Not recommended for use in dishwasher.
- Always use caution when cleaning the cutter. Keep fingers away from the cutter at all times.



Imported and distributed by Easylife Group Ltd, London NW1 0JP
Support Line: 0303 031 0777
 For more innovative products from Easylife please visit:
www.easylifegroup.com

 **easylife**TM
 Est. 1992 everyday solutions