

Disposal

- Please respect the environment.
- Dispose of the packaging according to the local recycling regulations.
- Dispose of the appliance at the end of its life span according to environmental consideration.

LED Beanie INSTRUCTION MANUAL



Model No. 2531 (Black) / 2532 (Grey)

Please read carefully before use and keep for future reference

Technical Specification

Beanie Size	One size fits all
Battery	3.7V Li-ion 250mAh
Charging Input	DC 5V 250mA
Charging Time	Approx. 1 - 1.5 hours
Lighting Duration	High: 90 mins Mid: 180 mins. Low: 240 mins.

Dear Customer,


Stylish, comfortable and warm, this innovative beanie hat has a brilliant extra feature. Fitted in the front there's a powerful LED headlight, so you can see your way on the darkest night while still keeping your hands free. Ideal for walkers, joggers, campers - in fact anyone out on foot after dark - the light has three brightness settings, a simple, push-on/off button and can be recharged directly via any USB port. Unisex and stretchy so one size fits all, our Beanie Headlight is available in Black and Grey and is knitted from a 35% acrylic, 65% polyester blend.



OPERATING INSTRUCTIONS:

Before initial use, fully charge the Removable Light Unit using a USB port. Charging typically takes 1 - 1.5 hours.

To remove the light unit from the beanie hat, simply push the unit upwards and out of the rim. (Fig 1)



Plug the USB Charger Plug into a USB port of Computer, Laptop or Car which has an output of DC 5V 1000mA-2000mA. It takes approximately 1 - 1.5 hours to charge fully.

The battery indicator light will illuminate red while charging, when battery is low or has partial charge. When fully charged, the indicator light will illuminate green.

After the Light Unit unit is fully charged, put the USB charger cover back on and then put the whole light unit back inside the rim of the beanie.


How to Operate Your LED Beanie

Caution: Do not use if product is damaged.

Once the Light Unit is fully charged, push the lamp into the hat rim.

Repeatedly press the On/Off switch (Fig 2) to cycle through the following functions:

There are 3 brightness settings: **high, mid and low**. Press once for high brightness, press again for middle brightness and press third time for the low bright light. To switch if off just press again.



Cleaning and Maintenance

Light Unit: Store Light Unit in a clean, dry and dark place.

When the device has not been in use for an extended period of time, charge the device at regular intervals to ensure optimum battery life.

Switch the Light Unit off and disconnect from charging socket before cleaning.

Clean the Light Unit with a soft, dry cloth. Do not use any form of abrasive cleaner or solvents to clean the unit. Never submerge the Light Unit in liquids.

Beanie : Machine washable at 30°C.

Ensure Light Unit has been removed before washing the beanie.

Do not bleach, do not tumble dry, do not iron, do not dry clean.

