









Compact 2-tier Dish Rack


INSTRUCTION MANUAL

Model No. 2761


Please read carefully before use and keep for future reference

PARTS LIST			
No.	Description	Photo	Qty (pcs)
①	Screw		8
②	Screw Cap		8
③	Spanner		1
④	End-caps		4
⑤	Anti-slip Mat		4
⑥	Long Anti-slip Mat		2

PARTS LIST			
No.	Description	Photo	Qty (pcs)
A	Frame		2
B	Upper Tier		1
C	Down Tier		1
D	Drip Tray		1
E	Cup Holder		1
F	Cutlery Holder		1
H	Cutting Board Holder		1



Install screw ① and screw cap ② on upper tier ③ and down tier ④, then fix to the frame ⑤, Then put cup holder ⑥, cutlery holder ⑦, drip tray ⑧ or cutting board holder ⑨ on the tier, finally, install end-caps ⑩ and anti-slip mat ⑪ or long anti-slip mat ⑫



Tips:

- 1: Please read the installation manual before install
- 2: Check carefully all parts are inside the packing
- 3: Finally, use the spanner to fix the dish rack
- 4: Clean it by dish cloth, do not use strong abrasive cleaner

Easylife Ltd, London NW1 0JP

Support Line: 0333 030 0777

© Easylife Ltd. 2022 (Reg. No. 05221840)

For more innovative products, please visit

www.easylife.co.uk

IN2761 © 2022 Easylife Ltd