

EMPTYING AND MAINTENANCE

CAUTION: Before opening, always release any remaining pressure by opening the safety valve.

1. Ensure it is vertical before releasing pressure.
2. Release any remaining compressed air in the system by pulling the safety valve firmly out.
3. Carefully unscrew the pump from the tank, ensuring that any remaining pressure is slowly released.
4. Empty the unit, disposing of any chemical waste properly and allow the tank to dry whilst open.
5. To clean the valves, spray pipe and nozzles, operate the unit with clean water or a solution of water and washing-up liquid.
6. The performance and working life can be increased by regularly lubricating the pump seal.
7. Use only resin and acid free lubricants.

⚠ IMPORTANT SAFETY INSTRUCTIONS

Incorrect use, (including transport and storage) environmental factors (storage, working environment) and insufficient maintenance can all lead to a shortened working life, for safety reasons the unit should be checked for visible damage each time it is used.

DISPOSAL

- Please respect the environment!
- Dispose of the packaging according to the local recycling regulations.
- Dispose of paper and cardboard packaging separately from plastic bags into the corresponding containers.
- Dispose of the appliance at the end of its life span according to environmental considerations.

TECHNICAL SPECIFICATION

Measurements: H98xW31xD27cm

Hose: 200cm

Lance: 80-126cm

Imported and distributed by Easylife Group Ltd, London NW1 0JP

Customer service: 0303 031 0777

For more innovative products from Easylife please visit:

www.easylifegroup.com

Portable Trolley Power Sprayer INSTRUCTION MANUAL



Model No. EL5252

Please read carefully before use and keep for future reference



Dear Customer

Thank you for purchasing the Trolley Power Sprayer.

Washing the car has just got simpler, quicker and more economical. And it's all down to this super Portable Trolley Power Sprayer. No outside tap, no mains electricity outlet? No problem. Just fill the 12 litre water tank, pump the handle to create pressure and you're in business.

Ideal for cars, motor cycles and caravans and boats too, it's supplied with two cleaning attachments.

Use the trigger-operated spray nozzle attachment for an initial power hose-down, then the specially designed cleaning brush attachment that seeks out dirt like a magnet. Finally, spray again for rinsing. Can be used with car shampoo.

Our wash and rinse Portable Trolley Power Sprayer will give you a showroom finish in no time. Includes a fully adjustable handle, cleaning brush, all terrain wheels, trigger nozzle and a two-metre hose.

No need for an outside tap, electricity or batteries

BEFORE USE

Check for any visible damage to the tank and all components before using.

INSTRUCTIONS FOR USE

FILLING THE TANK

1. Press down and turn the pump handle to lock it in place.
2. Unscrew the pump assembly by turning the locked pump handle to the right.
3. Fill the tank with the required amount of water. Do not exceed 12 litre limit. Guidelines are visible on the main tank.
4. Replace the pump and tighten.

USING TO WASH/CLEAN

1. Release the pump handle locking mechanism by pressing down and turning the pump handle.
2. Pump the handle around 25 times to obtain working pressure. If good pressure has not been reached at this point pump 5 more times and test. Continue until desired pressure is reached. Do not pump excessively as too much pressure build up could be dangerous.
3. The pump is equipped with a safety valve which releases excess pressure.
4. The Portable Trolley Power Sprayer is ready for use.
5. Screw handle firmly onto the hose.
6. Attach the lance by screwing firmly into place
7. Press the trigger to spray, release it to stop.
8. For a continuous flow of liquid, push the trigger lock until it clicks into place (Fig 1). Push the trigger lock back to it's original position to stop the flow of liquid.
9. Change attachments as required.



EXTENDING LANCE FITTING

Unscrew connector to free the inner pole. Do not fully unscrew these connections, you only need to loosen them to release the extending section of the lance.

Retighten when lance is extended to desired length.



STRUCTURE/COMPONENTS

1. Pump Handle
2. Funnel
3. Safety Valve
4. Tank
5. Wheels
6. Hose
7. Trigger
8. Trigger Lock
9. Nozzle
10. Brush
11. Lance

