



Bacon Chef

INSTRUCTION MANUAL

Model No. EL6230

Please read carefully before use and keep for future reference

PARCEL CONTENTS:

Main Tray
3 Struts

INSTRUCTIONS FOR USE:

1. Insert the struts into the holes in the main tray.
2. Place bacon over the struts, spacing apart slightly and cover with a kitchen towel
3. Put into the microwave for 3 minutes.
4. If you would like the bacon to be crispier add for another 1 minute, and continue until cooked to taste.
5. Drain away the fat and serve.

CLEANING INSTRUCTIONS:

Dishwasher Safe, separate struts from main tray before washing.

TECHNICAL SPECIFICATION:

Measurements: 23x22x12cm assembled. Material: PP