



Problem	Cause	Solution
Poor epilating results	You moved the epilator in the wrong direction	Move the appliance against the direction of hair growth, with the on/off button pointing in the direction in which you move the epilator
	You placed the epilating head on the skin at the wrong angle	Make sure you place the epilating head on the skin at an angle of 90° (see under heading "Using the epilator")
	You have used a cream or depilatory cream prior to epilating	Make sure your skin is clean, entirely dry and free from grease. Do not use any cream before you start epilating.
	The hairs are too short	Sometimes the hairs are too short to be caught. The optimal length for easy removal of the hairs is 3-4mm
Epilation cause skin irritation or injuries	This may occur on sensitive areas, particularly the first few times you epilate these areas	The first few times that you epilate sensitive areas, skin irritations and, in rare cases, injuries may occur, as the skin is very sensitive in these areas. We advise you to always stretch the skin with your free hand and to epilate before you go to bed at night, as this allows any skin irritation or rare bleeding points that may develop to disappear overnight. As you use the appliance more often, your skin gets used to it. To relax the skin, we advise you to apply a moisturising cream (for the bikini zone or the upper lip) or a mild alcohol-free deodorant (for the underarms) immediately after epilation or a few hours after epilation, depending on what is better for your skin
The epilator does not work	The battery is empty	Recharge the epilator correctly (see under heading "Charging the epilator")

**DISPOSAL**

- Please respect the environment!
- Dispose of the packaging according to the local recycling regulations.
- Dispose of the appliance at the end of its life span according to environmental consideration.

**TECHNICAL SPECIFICATION**

Model No: KD-190R	Operating voltage: AC 220-240V 2W 50-60HZ
Non-Removable Rechargeable Battery:	1.2V N2-MH (600 MAH)
Power cord length: 95cm	Measurement: L13xW5xD2.5cm

Imported and distributed by Easylife Group Ltd, London NW1 0JP

**Support Line: 0303 031 0777**

For more innovative products from Easylife please visit:

**www.easylifegroup.com**



# Rechargeable Hair No More INSTRUCTION MANUAL



Model No. EL1008 (KD-190R)

Please read carefully before use and keep for future reference




## Dear Customer,

Thank you for purchasing the Rechargeable Hair No More.

Embarrassing hair need no longer be an embarrassment - thanks to the Hair No More. Forget razors and harsh chemicals - Hair No More gentle rotating action works like fine tweezers but - it is estimated - 50 times faster. And because it delicately plucks every hair (even the finest and shortest) from the root, it helps prevent regrowth for weeks. With an integral LED light to illuminate the tiniest hairs, it's ideal for use on the chin, upper lip, cheeks, legs, bikini line and under arms. What's more, unlike a razor, Hair No More won't nick your skin or leave unsightly stubble or coarse hairs. Fully rechargeable for years of satisfaction, it comes with its own carry pouch and cleaning brush.

### Contents:

- A. Epilator
- B. Smart Light
- C. On/Off Slide Switch
- D. Charging Indicator
- E. Power Cord
- F. Cleaning Brush
- G. Yarn Pouch



### IMPORTANT

Read this user manual carefully before you use the appliance and save it for future reference.

### DANGER

- Keep the appliance dry.
- Do not use the appliance near or over a washbasin or bath filled with water.
- Do not use the appliance in the bath or in the shower to avoid leakage or electric shock.
- Do not connect the power cord and power supply during cleaning up the this appliance.
- Do not disassemble this epilator.

### ⚠ WARNING

- Do not use the appliance if the unit or power cord is damaged or broken to avoid injuries.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

### CAUTION


- The epilator is intended for epilating the underarms and arms, but it can also be used to epilate the bikini line, the upper lip, the chin and hard-to-reach areas, such as knees and ankles. Do not use the epilator for any other purpose.
- For hygienic reasons, the appliance should only be used by one person.
- To prevent damage and injuries, keep the running epilator away from scalp hair, eyebrows, eyelashes, clothes, threads, cords, brushes etc.
- Do not use the appliance on irritated skin or skin with varicose veins, rashes, spots, moles (with hairs) or wounds without consulting your doctor first.
- People with a reduced immune response or people who suffer from diabetes mellitus, haemophilia or immunodeficiency should also consult their doctor first.
- Your skin may become a little red and irritated the first few times you use the appliance. As you use the appliance more often, your skin gets used to epilation, skin irritation decreases and regrowth becomes thinner and softer. If the irritation has not disappeared within three days, we advise you to consult a doctor.
- Do not store the appliance at temperatures lower than 5°C or higher than 35°C.



### **Charging the epilator**

Recharge the epilator before using. Do not connect to the direct power during use. Please use the epilator after the recharge process completed.

- Switch off the epilator by push down the on/off button (Fig.2).
- Connect the power cord to epilator and connect power supply. The recharge indicator will light up to represent it is on charge (Fig.2-3)
- The Epilator can be used for up to 30 minutes continuously after a full charge of 8-10 hours.
- Do not charge the epilator over 15 hours.



### **Before you start epilating**

Note: Always clean the epilator before first use.

- When you use the appliance for the first time we advise you to try it out on an area with only light hair growth to get accustomed to the epilation process.
- We advise you to epilate before going to bed at night, as skin irritation usually disappears overnight.
- Epilation is easier just after taking a bath or shower. Make sure your skin is completely dry when you start epilating.
- Make sure your skin is clean, entirely dry and free from grease. Do not use any deodorant, makeup or cream before you start epilating.
- Epilation is easier and more comfortable when the hair has the optimum length of 3-4mm. If the hairs are longer, we recommend that you shave first and epilate the shorter regrowing hairs after approx. 1 week.
- As your hair grows in different cycles, it is best to epilate a few days in a row when you start epilating. This will help you remain stubble-free longer because your hair will start regrowing in the same cycle and pace.

### **During epilation**

- While epilating, stretch your skin with your free hand. This lifts up the hairs and helps to minimise the pulling sensation.
- Rub your skin to lift short hairs.
- For optimal performance, place the epilating head on the skin at an angle of 90° with the on/off slide pointing in the direction in which you are going to move the appliance. Guide the appliance across the skin against the direction of hair growth in a slow, continuous movement without exerting any pressure.
- On some areas, hair may grow in different directions. In this case, it may be helpful to move the appliance in different directions to achieve optimal results.
- If you sweat during epilation, dab your skin dry with a soft cloth.

### **After epilation**

- Use a soft deodorant without alcohol or a special deodorising cream for epilated skin after epilating the underarms.
- To relax the skin, we advise you to apply a moisturising cream immediately after epilation or a few hours after epilation, depending on what is better for your skin.
- Regular use of an exfoliating sponge or cream (e.g. during showering) 24 hours after epilation helps to prevent ingrowing hair, as the gentle scrubbing action removes the upper skin layer and fine hair can get through to the skin surface.



## Using the epilator

Use the epilator to epilate underarms, the bikini line, the upper lip, the chin and hard-to-reach areas.

Thoroughly clean the area to be epilated. Remove any residues of deodorant, cream etc. Then dab the skin dry.


Switch on the appliance

Place the epilating head at an angle of 90° onto the skin with the on/off slide pointing in the direction in which you are going to move the appliance. **Note: Always stretch the skin with your free hand.**

To epilate the bikini line or underarms, move the appliance slowly over the skin, against the direction of the hair growth.

Epilate your bikini line as shown in (Fig.4)

Epilate your underarms as shown in the figure, raise your arm to stretch the skin. Move the appliance in different directions to catch all hairs (Fig.5)




If you want to epilate the area around your mouth (upper lip and chin) follow the instructions opposite:

*Tips: We advise you to always epilate the area around your mouth before you go to bed at night, as this allows any skin irritation that may develop to disappear overnight. When you epilate the area around the mouth the first few times, skin irritation may occur in rare cases, as the skin in this area is very sensitive.*

- Place the epilator at an angle of 90° onto the skin and move the appliance slowly over the skin against the direction of hair growth (Fig.6)
- Note: To make the epilation as comfortable as possible stretch the skin around the mouth with your free hand. Do not press the epilator too firmly against the skin. Move the appliance slowly over the skin against the direction of hair growth.

You can also move the appliance in different directions to catch all hairs (Fig.7)



*Tips: To relax the skin, we advise you to apply a moisturising cream immediately after epilation or a few hours after epilation, depending on what is better for your skin.*

Do not use this appliance to remove hairs that grow out of moles.

Do not use this appliance to epilate eyebrows or eyelashes

## CLEANING & MAINTENANCE

- Never immerse the epilator in water or any other liquid, nor rinse it under the tap (Fig.8)
- Never use scouring pads, abrasive cleaning agents or aggressive liquids such as petrol or acetone to clean the appliance.
- Note: Make sure the epilator is switched off before you start to clean it.
- Note: Clean the appliance after each use to ensure better performance.
- Clean the epilator regularly by pulling off the epilating head cover and remove the hair with the supplied cleaning brush. Do not switch the appliance on while brushing (Fig.9). Clean the appliance with a dry cloth.

