

CLEANING INSTRUCTIONS

- Wash the Chip Pan in a dishwasher or by hand using mild, soapy water.
- Never use abrasive cleansers and scrubbers to clean the Chip Pan.
- Microwaves and internal wave guide covers must be kept clean. Please refer to microwave manufacturers' instruction manual for details on how to maintain and clean the wave guide cover.

DISPOSAL

- Please respect the environment!
- Dispose of the packaging according to the local recycling regulations.
- Dispose of paper and cardboard packaging separately from plastic bags into the corresponding containers.
- Dispose of the appliance at the end of its life span according to environmental considerations.

WARNING

This product is intended for domestic use only.

TECHNICAL SPECIFICATION

Measurements: 25cm (10") in diameter

Imported and distributed by Easylife Group Ltd, London NW1 0JP

Support Line: 0844 441 8448

For more innovative products from Easylife please visit:

www.easylifegroup.com

Microwave Chip Pan

INSTRUCTION MANUAL

FAILURE TO FOLLOW THE PRE-HEAT TIMES AS STATED MAY CAUSE POTENTIAL DAMAGE TO THE CHIP PAN OR MICROWAVE



Model No. EL4478

Please read carefully before use and keep for future reference

Support Line: 0844 441 8448
For more innovative products from Easylife please visit:
www.easylifegroup.com



Dear Customer

Thank you for purchasing the Microwave Chip Pan.

Specially designed for conventional, it's the easy way to cook mouth-watering, crisp, oven chips in under 6 minutes. And that's not all. Equally suitable for pizzas, chops, chicken, fish, bacon and omelettes, it's likely to be one of the most used pans in your kitchen. That's why it's durably made for years of delicious cooking and completely safe in your dishwasher.

Measures: 25cm (10") in diameter.

IMPORTANT SAFETY INSTRUCTIONS

- It is not necessary, nor recommended, to preheat longer than directed.
- Overheating can result in burning and smoking of the underside of the pan.
- Always use oven gloves when handling the chip pan after preheating and cooking.
- Only use in microwaves that have a glass plate or turntable.
- This pan is not conventional oven safe, only use microwave ovens.
- Contact with the side of the microwave may cause arcing and scorch the wall of your microwave. When placing the Chip Pan into your microwave, ensure the Chip Pan is in the centre and that there is space for it to rotate.
- Avoid heat-sensitive surfaces and plastic utensils as heat from the pan may cause melting.
- Always check that the food is fully cooked.
- Use plastic heat proof or wooden utensils with the Chip Pan.
- Do not use metal or cut with a knife on the Chip Pan surface.
- The base on the Chip Pan is made of a patented material which converts microwave energy into thermal energy. When pre-heated in a microwave oven the base will become extremely hot very quickly. The non-stick cooking surface will reach a temperature of around 200°C in 2 minutes. When food is added to the pre-heated Chip Pan the base will crisp and brown your food whilst the microwaves will cook the centre of the food to ensure evenly cooked results.
- Other than as directed in the pre-heat instructions never place the Chip Pan in the microwave without food.

WARNING

If the Chip Pan is used in a microwave oven smaller than specified there is a possibility of 'arcing', which in some circumstances could cause serious damage to your microwave oven. Please check that the dimensions of your microwave oven meet the following criteria before using.

IMPORTANT POINTS WHEN USING YOUR CHIP PAN

- As food heats from above, the chip pan distributes heat below it to brown and pan-fry.
- You **MUST** preheat the pan for it to work properly. The Chip Pan will be **HOT!** Use oven gloves when handling the pan.
- Make sure the food you want to crisp is in direct contact with the pan surface. Do not pile chips on top of one another and expect them to get crispy. Turning the food several times during cooking will ensure maximum crispness.
- Suggested times are going to vary based on variety, size and thickness of food. It is suggested to start with a lower heating time and work upwards by minutes until desired crispness is achieved.
- Check food halfway through for desired crispness on each side. To get all of your food cooked and crispy, each piece must make contact with the pan.
- Check food is fully cooked and piping hot all the way through before eating!

WARNING

The Chip Pan has a diameter of 25cm and is designed to be used in microwave ovens which allow a clearance of 1.5cm gap on all sides of the oven. As a guide if the Chip Pan sits on the turntable with no overhang it is suitable for use in that oven but we recommend you check the clearance is sufficient before use. The Chip Pan must not touch the internal sides of the microwave when in use. If the microwave does not have a turntable please ensure that the internal width of the microwave (left to right) and depth (front to back) are both at least 28cm.

If the microwave oven is smaller than these measurements then the Chip Pan is not suitable for use in it.

When using the Chip Pan always place it in the middle of the turntable or the microwave base. We recommend you check that the microwave is on a level surface before use to ensure that the Chip Pan does not move sideways when the turntable revolves.

MICROWAVE OVENS

To obtain the best results the Chip Pan should be pre-heated by microwaving on full power without food (it is safe to pre-heat this product without food) for the following times:

PRE-HEAT INSTRUCTIONS

1. Refer to the chart below for preheat times and your microwave owner's manual for oven power.
2. **It is not necessary, nor recommended, to preheat longer than directed. Over heating can result in burning and smoking of the underside of the pan.**

Oven Power	750W	850W	1000W	1200W	1500W
Preheat time:	2.5 mins	2 min	1.5 mins	1 min	45 secs

COOKING INSTRUCTIONS

1. Adjust cook times (based on 1200W microwave) as needed for other microwave wattage:

Oven Power	750W	850W	1100W	1500W
Adjustment to cooking time (based on 1200W):	Add 20 seconds per minute	Add 15 seconds per minute	Add 10 seconds per minute	Add 5 seconds per minute

COOKING INSTRUCTIONS - TIMES BASED ON A 1200W MICROWAVE

2. Refer to the chart below for reheating and cooking times. (Times given are estimates only. You should always check that food is cooked fully.)

Food	Quantity	Portion Size	Thawed Foods Time (minutes)	Frozen Foods Time (minutes)
Personal Pizza (frozen, thin crust)	1	5 oz.	N/A	3:00
Pizza/Bagel Bites	6	3 oz.	N/A	1:30
Slice of pizza (cold, thin crust)	1	1.25 oz. (quarter of 5 oz. pizza)	2:00	N/A
French Fries	18	3 oz.	1:15	5:00
Regular Oven Chips	18	4 oz.	N/A	8:00-10:00
Tator Tots	18	3 oz.	1:30	5:00
Mozzarella Sticks	4	4 oz.	1:00	1:15
Onion Rings	6	3 oz.	0:45	4:00
Hash Browns	1	2 oz.	1:00	5:00
Chicken Fingers	3	3 oz.	1:30	5:00
Chicken Nuggets	4	4 oz.	1:30	3:00
Fish Fillet	1	2 oz.	2:00	4:00
Fish Sticks	6	3 oz.	1:30	3:00
Bacon ("thick-cut")	4 slices	4 oz.	6:00-8:00	N/A
Omelette (4 large eggs+ 50ml milk)	1	10 oz.	6:00-8:00	N/A